

# XT-16

## Combo Dispenser

H.PU<sup>®</sup> 弘普

This dispensing unit represents a unique integrated design, it dramatically saves space and costs maintaining a very compact footprint. This integrated structure is the ideal solution for modern retail stores where space is a premium and maximum efficiency is required. The integrated structure is designed to grant maximum accessibility for both normal use and maintenance.



XT-16

### Basic features

- Manual dispenser and mixer integrated machine
- 16 canisters with selection of pump technology
- Compatible with water based or universal colorants
- Canister real capacity of 2 liters/quarts
- 2 Ounces (60 ml) stainless steel piston pumps
- Dispensing precision up to 1/384 fl oz (0.077 cc)
- Automatic colorant mixing (5 min every 6 hours, factory adjustable)
- Safety switch on the mixer access door

### Options

- Digital metering, single and double gauge pump settings
- Different dispensing unit/shot scales
- White or black canister body
- Manual can puncher (takes one canister position)
- Custom body colors
- 110V 60Hz power settings

### Can handling

- Maximum load 35 Kg (77 lb.)
- Maximum can height 420 mm
- Minimum can height 60 mm
- Maximum can diameter 330 mm

### Power and electric specs.

- Single phase 220 V 50 Hz  $\pm$  10%
- Max. power consumption 790 W
- Working temperature from 10° to 40°
- Relative humidity from 5% to 85% (not condensing)

### Dimensions and shipping

- Size (H, W, D) 1480 x 800 x 770 mm
- Weight 225 Kg (455 lb.)
- Wood crate standard package
- Shipping size (H, W, D) 1630 x 920 x 1000 mm
- Shipping weight 265 Kg (535 lb.)
- 20' Container can contain up to 14 units (28 units in 40')



### HONGPU MACHINERY MANUFACTURE CO., LTD.

Add: North Industrial Rd., Lunjiao, Shunde, Guangdong, China

postcode: 528308

TEL: +86 757 2362 3133 / 2362 3138

FAX: +86 757 23622787

E-mail: [info@hpuchina.com](mailto:info@hpuchina.com)

<http://www.hpuglobal.com>